


Front

Vorderseite / Face avant / Parte anteriore /
Parte delantera / Вид спереди / Parte frontal



2D



3D ▲



No driver installed

Kein Treiber installiert

Aucun pilote installé

Nessun driver installato

No se ha instalado el controlador

Драйвер не установлен

Nenhum driver instalado

USB IR Emitter

USB-IR-Sender / Émetteur IR USB / Emittitore
IR USB / Transmisor de infrarrojos USB /
USB ИК эмиттер / Emissor IV via USB

Designed to be used with 3D Vision wireless
glasses with products without a built-in
IR emitter.

Zur Verwendung mit 3D Vision Wireless-
Brillen für Produkte ohne integrierten
IR-Sender.

Conçu pour une utilisation avec les lunettes
sans fil 3D Vision et les produits dépourvus
d'un émetteur IR intégré.

Progettato per l'utilizzo con gli occhiali
wireless 3D Vision per prodotti senza
emittitore IR integrato.

Diseñado para usar con gafas inalámbricas
3D Vision en productos sin transmisor de
infrarrojos integrado.

Предназначен для использования с
беспроводными очками 3D Vision
для устройств без встроенного
ИК-передатчика.

Desenvolvido para ser usado com óculos
3D sem fio para produtos sem um emissor
infra-vermelho integrado.



176-0139-000

Back

Rückseite / Dos / Retro / Parte posterior /

Вид сзади / Parte traseira

